



Quick Install Guide and Warranty Information



6-in-1 Installation Instructions

Installation on Macintosh Systems

We strongly recommend using Mac OS 9 or greater when operating the EDGE Digital Media USB Reader. Computers running Mac OS versions between 8.6 and 9.0 must first update their OS with Apple's USB Adapter Card Support for Mass Storage devices before using USB devices. *Please do not connect the reader before you turn your machine on!*

For Mac OS 8.6/9.X Users

1. Before connection of the USB Reader, turn on the Macintosh and boot as normal.
2. Insert the driver CD into the CDROM Drive. Double Click the CDROM icon and find "UsbCardReader" and launch it.
3. Check the "Standard Installation" option, then click "Install." Follow installation instructions accordingly to completion. After the installer completes, please reboot the system.
4. Once the system reboots, connect the 6-in-1 Reader to the computer with the supplied cable and insert your digital media card(s).
5. For each card you insert, your computer will show a new drive icon on your desktop.
6. The digital media card may now be used as a portable storage device, accessible through standard file access methods.

For Mac OS X Users

1. To utilize the reader under Mac OS X, you must be using version 10.1.2 or greater. You do not need to use the supplied driver CD.
2. Connect the 6-in-1 Reader to the computer with the supplied cable and insert your digital media card(s). Your computer will automatically detect the card(s) as you install them.
3. For each card you insert, your computer will show a new drive icon on your desktop.
4. The digital media card may now be used as a portable storage device, accessible through standard file access methods.

Prior to removing the digital media card(s) from the reader, click and drag the new disk icon(s) to the trash folder on your desktop to disconnect your card(s). Failure to do so may result in data corruption and render the card(s) unusable.

Installation on a Windows ME or XP Systems

EDGE Digital Media USB 6in1 Readers use 'Mass Storage Compliant' technology. This means that users running Windows ME, 2000 or XP are not required to install any device drivers to operate the reader.

Please do not connect the reader before you turn your machine on!

1. Connect the Reader's USB plug to the USB port on your PC or USB Hub.
2. The Operating System should automatically install all needed drivers without your aid.
3. The 6-in-1 Reader should now show up in "My Computer" as four additional removable drives, one for each port on the reader.
4. When inserted into the reader, any digital media card(s) may now be used as a portable storage device, accessible through standard file access methods.

5. The digital media card may now be used as a portable storage device, accessible through standard file access methods.

Prior to removing the digital media card from the reader, the card must be disconnected. Failure to do so may cause data corruption and render the card unusable.

To disconnect the card, proceed with either of the following steps:

- A. Double-click the "My Computer" icon on the desktop. Right-click on the appropriate removable disk icon and select the "Eject" option. Wait for the disconnect confirmation prior to removing the card.
- B. Left-click on the PC card with a green arrow in the system tray. On the pop-up menu, highlight the appropriate card you want to remove, then select "Stop USB Mass Storage Device." Wait for the disconnect confirmation prior to removing the card.

Installation on PC Compatible running Windows 98, 98 SE, or 2000.

Please do not connect the reader before you turn your machine on!

1. Insert the supplied Driver CD into your CDROM Drive.
2. Double click on the "My Computer" icon on your desktop.
3. Double click on the CDROM drive icon. Once opened, double click on the "Setup" icon. It will install the software automatically, then ask you to reboot your computer.
4. Once your machine has rebooted, connect the Reader's USB plug to the USB port on your PC or USB Hub.
5. The 6-in-1 Reader should now show up in "My Computer" as 4 additional removable drives, one for each port on the reader.
6. The digital media card may now be used as a portable storage device, accessible through standard file access methods.

Prior to removing the digital media card from the reader, the card must be disconnected. Failure to do so may cause data corruption and render the card unusable.

To disconnect the card, proceed with either of the following steps:

- A. Double-click the "My Computer" icon on the desktop. Right-click on the appropriate removable disk icon and select the "Eject" option. Wait for the disconnect confirmation prior to removing the card.
- B. Left-click on the PC card with a green arrow in the system tray. On the pop-up menu, highlight the appropriate card you want to remove, then select "Stop USB Mass Storage Device." Wait for the disconnect confirmation prior to removing the card.

EDGE Digital Media-USB Readers

ONE-YEAR LIMITED WARRANTY

EDGE Digital Media-CF, SM, SD, MMC

FIVE-YEAR LIMITED WARRANTY

This product is warranted to be free of defects in materials and workmanship and to function in accordance with manufacturer's specifications for the appropriate period of time (1 year-USB Reader products, 5 years-Card Products) from the date of purchase.

This warranty applies only to the original purchaser, and no warranty or liability exists for loss of any data or for software, nor for damage to hardware, caused during or after installation of the product. No warranty or guarantee of any kind shall exist for repair, replacement or refund of any item damaged directly or indirectly as a result of installation or use of the product.

Acceptance of this product constitutes purchaser's agreement that Peripheral's sole obligation under this warranty shall be repair or replacement of the product or refund of the full original purchase price, at Peripheral's option. Under no circumstances whatsoever will more than the full original purchase price be deemed payable. No warranty exists for damage or destruction of a willful nature, caused deliberately by any person or arising from use of the product for anything other than its intended use by the manufacturer and/or distributor. No warranty exists for repairs of any damages caused by natural disasters or acts of God, including electrical surges or static electricity emissions. No warranty exists for damages resulting from modifications made to the product by any unauthorized person.

If you need assistance with your EDGE Digital Media™

Product Within the U.S. call Toll-Free: 800-332-6581

Outside the U.S. call: 580-332-6581

To register for your warranty go to www.peripheral.com/register

EDGE Digital Media™ is a trademark of Peripheral Enhancements Corporation.

6-in-1 Usage Diagram

